

WiFi SOUNDBOX



CT-ETWF3004-BL
WiFi SoundBox

Introduction

The WiFi SoundBox can make the sound source signal extend to every room, home kitchen, living room, balcony and every corner. It allows you can listen to the beautiful music in each room. For example, you can enjoy the melodious music when you are watering the flowers on the balcony, what's more, when you eat at a restaurant, bathing in the bathroom, reading in the library, still can enjoy the beautiful background music, which make you comfortable to spend every moment. The WiFi SoundBox, with its unique personalized design, fully meet the demand of music in people's home life. The intelligent high-tech design, let the whole system more humane, In addition, it is more convenient and flexible for people to control.

The device using WiFi technology, support one-click configuration, and also has the advantages of low complexity. What's more, we can set blossoms through the six digital key, which is more convenient and fast.

Technical Information

- 60Hz-20KHz super widescreen, ensure HD lossless sound quality, make music more pure

- Double passive radiator, low frequency and freely, bring a sense of hierarchy
- We can choose the set of music sources, according to personal preferences to do collocation

Specifications

- Radio protocol : WiFi (802.11 b/g/n)
- Power supply : DC 5V
- Input current : 1.5A
- Rated power : 2 x 10w
- Speaker : 2 x 35mm
- Frequency response : 60Hz ~ 20KHz.
- The signal-to-noise ratio : > 85dB
- Dimension : 197mmx65mmx67mm

Operation

The indicator LED and the interface of the WiFi SoundBox are shown in figure1.






Fig.1

Including of WiFi Network

- 1) Ensure the WiFi SoundBox with adequate power, and in the power-on state.
- 2) Press and hold the WiFi button for 5 seconds, the button will flash quickly with a white light about 5-6 times / seconds (a voice would be prompt at this time: please use APP to configure the network) confirming the device has been in network inclusion mode.
- 3) Choose " Broadlink " to enter the Network Inclusion mode on the APP, then click "  ".



- 4) Check the status of the WiFi Indicator LED, if the white light flashes slowly confirming the device is connecting to the wireless network (a voice would be prompt at this time: connecting to the network, please wait patiently), if the white light stop flashing confirming the device has been included into the network.
- 5) Please go to the device list interface, and refresh the device list, the device will be displayed.

Installation Instructions

INSTALLATION PLACE

This device is small in size, can be arbitrarily placed. In addition, when you install the WiFi SoundBox, it is not need wiring require and only need to insert the adapter into proper place, which can make the installation completed.

INSTALLATION TIPS

- a) The adapter specification: Input: 100V-220V AC

Output: 5.0V==1.5A

- b) Because this device is a WiFi device, please place it in the WiFi range, in order to ensure the remote control effect when installing.



Safety Notice

- This device is a wireless communication product, please do not place the device to work in the metal container, in case the signal is blocked.
- Keep the device away from a strong sunlight, humidity, high temperature, dust or mechanical shock.
- Keep the device away from acid-base and other corrosive solids, liquids, gases, to avoid damage.
- Keep the device away from the magnet, speaker or TV.
- Please clean horn surface with a soft brush regular to ensure the sound effects.